



Instruction Sheet For Tool #1707

Spreading Tool

Use on all 1980-94 5-Speed Rubber Mount Big Twins



1. Refer to H.D.® Service Manual for specifications.
2. Install cleverbloc spreading tool between swing arm cleverblocs. Lube all threads.
3. Turn nuts with a 3/4" wrench to spread the cleverblocs apart to approximately 4.600 inch.

CAUTION: Wear safety glasses. Excessive force may damage parts and tool.
See JIMS® catalog for over 100 other top quality professional tools.
The last tools you will ever need to buy.

"Doing It Right...The JIMS Way!"

555 Dawson Drive, Camarillo, CA 93012 • Phone 805-482-6913 • Fax 805-482-7422